

## Instructions for Remote IR Kit

- 1) Insert Batteries into High Power infrared Philips Remote
- 2) Click “**TV**” button once, on upper left corner area of the Philips Remote
- 3) Now you’re ready to record!
- 4) To start LS-10 Recorders, press and HOLD the **Play** button, until both recorders light up, then release the Play button
- 5) To stop LS-10 Recorders press and release the **Stop** button.

Notes:

*The other buttons on the remote are not used.*

*If the recorders are already recording, pressing the **Play** button on the High Power infrared Philips remote will put recorders in RECORD PAUSE mode, if desired. To go back to recording, just press the Play button again.*

